


SCHÜTTE SF26 - AF26

S13/003 101718
Dźwignia zacisku
C3220C-23Z



S9/002
Mufa zacisku
C3210A-22Z




S13/005 101717
Dźwignia zacisku
C3220B-23Z



S13/004 101716
Dźwignia zacisku
C3220A-23Z




SCHÜTTE SF26 - AF26



579

S14/012
Rura posuwu
D3080-22Z

$\varnothing 40$




S15/040
Nakrętka
D3063-23



S14/013
Pierścień ustalający
D3260A-22


SCHÜTTE SF26 - AF26




S5/036P Oś




S8/033P Oś




S8/031P Oś




S8/035P Oś




S8/030P Oś




S8/034P Oś



S8/031R Rolka



S5/036R Rolka



S8/030R Rolka

S8/036
Śruba do krzywek
C5820A-44M
2.81.15.68.1



S8/060B
Dystans
C5830A-44M



S8/060
Dystans
C5830A-67M
2.24.28.35.1

